



PANTO POP

Design by VERNER PANTON



1

Take the chairs out of the box.
Be careful not to scratch the
surface of the chairs!





Maintenance of Panto Pop:
Wipe off surfaces with a damp cloth. Grease stains can be removed with soapy water. Do not use abrasive cloth or substances as it will scratch the surface.

Notice:
For both indoor and outdoor use!



VERPAN A/S
Egeskovvej 29
8700 Horsens
Denmark

Tel. +45 76 58 18 82
Fax +45 75 61 00 05

www.verpan.com
info@verpan.com